# illbruck making it perfect.

### **Description**

GS200 is a gun grade, acetoxy cure silicone sealant with fungicide.

### Colour

Translucent and white

### **Packaging**

310 ml cartridge (20 per carton)

### **Technical Information**

Characteristic	Standard	Classification
Composition		acetoxy cure silicone sealant with fungicide
Specific Gravity	ISO 1183-1A	0.98
Consistency	ISO 7390, profile U20	non-sag
Shore A Hardness	ISO 868	18
Skin Forming Time	at 23°C, 50% RH	25 minutes
Tack Free Time		Approximately 40 minutes
Cure Rate	at 23°C, 50% RH	1 - 2 mm/1 <sup>st</sup> day
Tensile Strength	ISO 8339	0.6 N/mm <sup>2</sup>
Modulus at 100% Elongation	ISO 8339	0.36 N/mm²
Elongation at Break	ISO 8339	150%
Movement Accommodation		20%
Elastic Recovery	ISO 7389	95%
Application Temperature		+5°C to +40°C
Service Temperature		-40°C up to +100°C
Storage		Store in shaded dry conditions between +5°C and +25°C.
Shelf Life		18 months when stored as recommended in original unopened containers.

### **Necessary Tools**

· Cartridge gun and sharp knife.

### **Protective Equipment**

Use in well ventilated conditions and ensure all recommended protective equipment is worn during handling & use of this product. For full recommendation, refer to safety data sheet.

### **Priming**

 GS200 has excellent primerless adhesion to many typical construction materials. For special situations, or if in doubt, please contactTremco CPGTechnical Services Department to discuss your requirements.


### **Joint Design Considerations**

- Joint design to be in accordance with BS 6093.
- For the purposes of joint width calculation in BS 6093, the MAF of GS200 is 20%
- Width to depth ratio of GS200 should be 2:1



### **GS200**

### Sanitary Silicone



### Usage / Purpose

GS200 is a rapid curing, sanitary grade silicone sealant with excellent resistance to mould and mildew. It is ideal for applications in: bathrooms, showers and wet rooms; kitchens; changing areas and hospital sluice rooms. Excellent un-primed adhesion to glass, ceramic tiles, many plastics and paint coatings, vitrified substrates.

### Key Benefits

- Contains powerful fungicide to prevent mould growth
- Wide service temperature range: -40°C to +100°C
- Accommodates joint movement up to 20%
- Excellent resistance to detergents and cleaning





## Sanitary Silicone



- The minimum contact area with any substrate (including for fillet joints) should be determined by the quality of the bond. If in doubt, please contactTremco CPG.
- Sealant width not to be less than sealant depth.

### **Surface Preparation**

- Joint faces should be clean, dry and free from dust, oil, grease, old sealant and any traces of contaminant which may affect adhesion. Any previously applied sealant must be mechanically removed.
- Thoroughly clean with a suitable cleaning solvent using the two cloth method, using one cloth dampened with the cleaning product to lift contaminants and a second clean dry cloth is used to remove any cleaner residue.
- Apply masking tape to prevent contamination of adjacent surfaces
- ContactTremco CPGTechnical Services Department for further information if required.

### **Joint Backing**

 Deep joints should be filled with an approved material such as FM330 or FM365 PU Foam. In movement joints, back fill the joint with polyethylene joint backing in order to control the depth of sealant and prevent three-sided adhesion.

### **Application**

- Always carry out a test application prior to installation, to confirm compatibility and suitability for use
- Application should be in accordance with BS 8000:16
   "Code of practice for sealing joints in buildings using scalants"
- Apply between +5°C and +40°C using a conventional skeleton gun or electric/power equipment
- All beads should be tooled after application to ensure firm, full contact with the joint faces.
- Tooling should commence without delay due to the rapid skinning of the product.

### Coverage

Width x Depth (mm)	Linear metres per 310 ml Cartridge
6 x 6	8.6
10 x 6	5.2
10 x 10	3.1
20 x 10	1.6
25 x 12	1.0

Fillet Joint Width x Depth (mm)	Linear metres per 310 ml Cartridge
6 × 6	17.0
10 x 10	6.2

### Cleaning

Remove excess sealant immediately with AT200 High Strength Cleaner. Ensure surface is solvent resistant before cleaning. Cured sealant can only be removed mechanically.

#### **Please Note**

Not recommended for materials where migration of constituents can take place (e.g. certain rubbers), permanent immersion or over painting. Do not use where abrasion or physical abuse will be encountered (e.g. trafficable joints). Not suitable for use in aquariums or contact with coated and laminated glass, structural glazing, polycarbonate/polyacrylate, lead, copper, brass, zinc or galvanised steel. Also unsuitable for use on natural stone and other porous substrates where staining and or chemical reaction can occur.

### **Health & Safety Precautions**

Safety data sheet must be read and understood before use.







### **Technical Service**

Tremco CPG UK Limited has a team of experienced Technical Sales Representatives who provide assistance in the selection and specification of products. For more detailed information, service and advice, please call Customer Services on 01942 251400.

### **Guarantee / Warranty**

Tremco CPG UK Limited products are manufactured to rigid standards of quality. Any product which has been applied (a) in

accordance with Tremco CPG UK Limited written instructions and (b) in any application recommended by Tremco CPG UK Limited, but which is proved to be defective, will be replaced free of charge.

No liability can be accepted for the information provided in this leaflet although it is published in good faith and believed to be correct.

Tremco CPG UK Limited reserves the right to alter product specifications without prior notice, in line with Company policy of continuous development and improvement.



### **Tremco CPG UK Limited**

Coupland Road Hindley Green, WIgan WN2 4HT United Kingdom T: +44 1942 251400 F: +44 1942 251410

info.uk@cpg-europe.com www.cpg-europe.com